

**DA-816 ANALOG  
OUTPUT UNIT**

**FEATURE  
OVERVIEW**

Assign personal mixes  
to analog outputs

Eight stereo output pairs  
(16 TRS connectors)

High quality conversion

Simple setup with a  
CS-SOLO or CS-DUO

LED and test tone connection  
verification and setup aid



The DA-816 output rack unit is for connecting to wireless in-ear transmitters, powered monitors or powered house speakers. The DA-816 connects to the MIX-16 or MIX-32 via shielded CAT5e network cable. Each DA-816 provides eight stereo TRS outputs.

The DA-816 provides stereo balanced outputs for 8 personal mixes. Flexible SoftRoute™ mix assignments and test tone capabilities, make for quick setup.

Front panel LEDs indicate a personal mix is assigned to one or more of the outputs. When the Output ID feature is enabled and an output is selected, the front panel LED illuminates and a test tone is sent to the output.

**DA-816 SPECIFICATIONS**

THD+N	.0019%
S/N Ratio	104 dB
Full Scale Output	+4dBu / 19dB peak
Output Impedance	300Ω
Max cable length from MIX-16/MIX-32	100m CAT5e (shielded cable required)
Dimensions	19" (483mm) W 6.25" (159mm) D 1U, 1.75" (44mm) H
Weight	4.16 lbs (1.89kg)

**WHOLE SYSTEM**

	.03% (100mW, 22Ω)
THD+N (18 dBu 1kHz input)	.014% (100mW, into 32Ω)
	.005% (100mW, into 64Ω)
	.003% (100mW, into 300Ω)
S/N Ratio	103dB
Frequency Response	20Hz-22 kHz ± 3dB
Crosstalk (Left to Right)	-103 dB
Latency	1.5 ms

**FOR ORDERS CONTACT:**

sales@digitalaudio.com

Phone: 952-401-7700


Fax: 952-401-7725

**DIGITAL AUDIO LABS**


1266 PARK RD CHANHASSEN, MN 55317

WWW.DIGITALAUDIO.COM

**FRONT**



**REAR**



**1. External Power Supply Connector**

**2. Livemix Data In:** Connects to a Livemix Data Out port on the MIX-16 or MIX-32.

**3. Power Switch**

**4. Outputs 1-8 LEDs:** Visual indication that a personal mix is assigned to one of the stereo outputs. These LEDs can also be used for identification and troubleshooting purposes.


**5. Option Card Slot:** This is for future expandability.

**6. Livemix Data Status LED:** Indicates connection status with the MIX-16 or MIX-32.


**7. USB Port:** The USB port allows the firmware of the DA-816 to be updated through connection to a Windows PC.

**8. TRS Outputs:** 16 Balanced TRS connections in eight stereo pairs for connecting to external devices, like wireless in-ear transmitters, powered monitors, snakes, etc.

### CONNECTING THE DA-816 TO THE MIX-16 AND MIX-32



### CONNECTING TWO DA-816 UNITS TO THE MIX-32



### CONNECTING THE DA-816 TO EXTERNAL DEVICES

